



# ADEMCO Vista-15

## Keypad/Console Command Summary

| Command / Function Name          | Syntax  | Comments/Notes   |
|----------------------------------|---|--|
| Entering Program Mode            | Installers Code + 8 + 0 + 0<br>(default = 4112) | If this does not work then power down then up & hit * + # simultaneously within 50 seconds             |
| Arming Away                      | Code + 2  | This arming mode gives you exit & entry delays & arms perimeter & interior zones.                      |
| Arming Stay                      | Code + 3  | This arming mode gives you exit & entry delays & arms perimeter zones. Interior bypassed.              |
| Arming Night Stay                | Code + 3 + 3                                    | This arming mode gives you exit & entry delays & arms perimeter zones + zone list 5.                   |
| Arming Instant                   | Code + 7  | This arming mode gives you exit & no entry delay & arms perimeter zones.                               |
| Arming Maximum                   | Code + 4  | This arming mode gives you exit but no entry delay & arms perimeter & interior zones.                  |
| Quick Arming                     | # + 2,3,33,4, or 7                              | Must have a master code programmed in user 2   |
| Disarming                        | Code + 1  |  |
| Bypass                           | Code + 6 + Zone #                               | Always Enabled   |
| Quick Forced Bypass              | Code + 6 (wait 2 seconds)                       | If enabled in field *23  |
| Chime Mode                       | Code + 9  | Chimes on perimeter & entry/exit zones   |
| Site-initiated download          | Code + # + 1                                    | Calls modem at offsite computer  |
| Virgin Download                  | Code + # + 5                                    | System must be defaulted & it will only answer 1 time after the 4 <sup>th</sup> ring.                  |
| Turning On Relay                 | Code + # + 7 + Relay Number                     |  |
| Turning Off Relay                | Code + # + 8 + Relay Number                     |  |
| System Test                      | Code + 5  | Code + 1 exits   |
| Transmitter ID Sniffer Mode      | Code + # + 3                                    | Displays all numbers, which disappear when transmission is received, to exit hit code + 1              |
| Go/No Go Test Mode               | Code + # + 4                                    | Puts receiver in ½ gain mode, to exit hit code + 1   |
| Setting the CLOCK                | Code + # + 63                                   | Press * to enter set mode. *moves right, # moves left. Once you get back to the first screen, # saves. |
| Adding User Codes                | Master code + 8 + user 03-13 + new code         | 15 is arm only   |
| Adding Temporary Babysitter Code | Master code + 8 + 14 + Duress code              | Can only disarm if this code armed it. Once master code is used, this code auto-deletes.               |
| Adding Duress Code               | Master code + 8 + 15 + Duress code              |  |
| Adding a master code             | Installer code + 8 + 02 +                       |  |
| Changing master code             | Master code + 8 + 02 + new code + new code      |  |
| Display faulted zones            | *   |  |
| Silence Fire alarms              | 1   | Code not needed.   |
| Silence Battery                  |   | Code + off required to clear memory.   |