


Section 23: SETTING THE REAL-TIME CLOCK

This section provides the following information:

- General information about the real-time clock
- Setting the time and date

General Information

This system provides a real-time clock, which must be set in order for the system's event log to keep track of events by time and date. It must also be set in order to execute scheduling programs (time-driven events).



Use a 5137AD or 6139 alpha keypad to set the real-time clock, or set the clock via the Downloader software. Only users with installer or master authority level can set the real-time clock.

Setting the Time and Date

1. Enter installer or master code + # 63. Typical display shows

TIME/DATE	—	THU
12:01 AM		01/01/90

2. The day of the week is automatically calculated based on the date entered. Time and date entries are made by simply entering the appropriate hour, minute, month, day and year.

Press the key to accept the entered value. The cursor then moves to the right.

Press the key to move the cursor to the left of the display, to the previous position.

Enter the correct hour then press to move to the minutes and make the correct entry.

Press again, then press any key 0-9 to set AM/PM. Press any key again to change AM to PM, or PM to AM.

Press to move cursor to the month position and enter the correct month using a 2-digit entry.

Press and enter the correct date.

Press and enter the correct year.

3. Exit clock mode by pressing the key after the cursor is in the year position.