



I N S T A L L A T I O N G U I D E



MDC-108 Coax Distribution Module

12382 south gateway park place, 700, draper, utah 84020
1.801.617.3100
www.futuresmart.com

The FutureSmart MDC-108 Coax Distribution Module provides distribution of one incoming coax signal (TV or Cable TV) to 8 locations, and Satellite TV to 2 locations. Please be sure to review this installation guide carefully prior to installation.

Installing the MDC-108 Coax Distribution Module


Connecting TV, and Cable TV

1. Run a RG6 coax cable from the video source (antenna or Cable TV) to the MDC-108 coax distribution module.
2. Connect the RG6 coax cable to the input on the rear of the MDC-108 coax distribution module.

**Input for
Antenna
Television or
Cable TV**




3. Connect the RG6 coax cable running to the rooms to the outputs on the front of the MDC-108 coax distribution module. If you are using MDP3 patch modules, use coax patch cords to connect the zones and the outputs.



Connecting Satellite TV (KU Band Only)

1. Run 2 RG6 coax cables from the Satellite Dish to the MDC-108 coax distribution module. One will be designated as LNB A and the other as LNB B.
2. Connect the LNB A and LNB B RG6 coax cables coming from the Satellite dish to the SATV inputs on the back of the MDC-108 coax distribution module.



3. Connect the RG6 coax cable running to the Satellite Receivers in the rooms to the SATV outputs on the front of the MDC-108 coax distribution module. If you are using MDP3 patch modules, use coax patch cords to connect the zones where the receivers are located with the SATV outputs.

