

ADEMCO GROUP TECHNICAL SUPPORT KNOWLEDGEBASE
STEP-BY-STEP PROCEDURE

Created: 8.30.2001
Modified: 8.30.2001
File: V15p_14.Doc
Pages: 3

Product: Vista-15P
Title: Programming Keypad Panics

1. Enter Programming, Installers Code (4112) + 8 + 0 + 0 or Power down then back up & press the * + # keys simultaneously within 50 seconds.

2. Screen Displays:
INSTALLER CODE
20

3. Press *56, screen displays:
Set to Confirm?
0=No , 1=Yes 0
Enter 1 or 0 then press [*]
NOTE: If using the *58 expert mode skip to step 10.

NOTE: Keypad Panics are zones 95 (1+*), 96 (3+#), & 99 (*+#). The A, B, C, & D keys can be programmed as panics in *57 Function Key Programming

4. Screen Displays:
Enter Zn Num.
(00 = Quit) 01
Press 95 then [*]

4. Screen displays:
ZN ZT - RC IN : L
95 09 10 -- : -

NOTE: This is a summary screen that displays the current values for this zone. ZN is the zone number, ZT is the zone response type, RC is the report code, IN is the input type & L is not used.

5. Press [*], screen displays:
95 Zone Type
Fire 09
Enter the desired value for this zone.

NOTE:	00 = NOT USED	12 = 24Hr. MONITOR
	01 = ENTRY/EXIT #1	14 = Carbon Monoxide
	02 = ENTRY/EXIT #2	16 = Fire w/ Verify
	03 = PERIMETER	23 = NO ALARM RESPONSE
	04 = INTERIOR FOLLOWER	24 = SILENT BURGLARY
	05 = TRBLE DAY/ALARM NIGHT	25 = 24-HR. NON-ALARM
	06 = 24Hr. SILENT	08 = 24Hr. Aux.
	07 = 24Hr. AUDIBLE	09 = FIRE

6. Press [*] to continue, screen displays:
95 REPORT CODE
1ST 01 2ND 00 10
Enter the report code for this zone.

ADEMCO GROUP TECHNICAL SUPPORT KNOWLEDGEBASE
STEP-BY-STEP PROCEDURE

Created: 8.30.2001
Modified: 8.30.2001
File: V15p_14.Doc
Pages: 3

NOTE: Report code values are in hexadecimal form & range from 01-15. A = 10, but sends a 0 to central, B = 11, C = 12, D = 13, E = 14, & F = 15.

7. Press [★] to continue, screen displays:
ZN ZT - RC IN : AD
95 07 - 10 -- : -
This is the ending summary screen & shows any changes made to this zone.

8. Press [★] to continue, screen displays:
PROGRAM ALPHA?
0 = NO , 1 = YES 0
If you want to program alpha descriptors for this zone press 1 & refer to adding descriptors document, otherwise press 0 then press [★]

9. Screen displays:
ENTER ZN NUM.
(00 = QUIT) 96
Repeat steps 3-8 or press 00 to exit the ★56 menu mode, then press ★99 to exit program mode.

Use the following steps for programming panics using the Expert Mode:

10. Press ★58, screen displays:
Set to Confirm?
0=No , 1=Yes 0
Enter 0 or 1 then press [★]

11. Screen displays:
ZN ZT - RC IN : RT
01 09 - 10 HW : 1

**NOTE: ZN = Zone Number
ZT = Zone Response Type
RC = Report Code
IN = Input Type
L = Loop Number**

12. The cursor should be flashing under ZN, enter zone number 95 then press the [★] key.

13. The cursor should be flashing under ZT, enter the zone type you wish to use or press the "C" key to copy the previous zones attributes.

NOTE: 00 = NOT USED	12 = 24Hr. MONITOR
01 = ENTRY/EXIT #1	14 = Carbon Monoxide
02 = ENTRY/EXIT #2	23 = NO ALARM RESPONSE
03 = PERIMETER	24 = SILENT BURGLARY
04 = INTERIOR FOLLOWER	25 = 24-HR. NON-ALARM
05 = TRBLE DAY/ALARM NIGHT	07 = 24Hr. AUDIBLE
06 = 24Hr. SILENT	08 = 24Hr. Aux.
09 = FIRE	

ADEMCO GROUP TECHNICAL SUPPORT KNOWLEDGEBASE
STEP-BY-STEP PROCEDURE

Created: 8.30.2001
Modified: 8.30.2001
File: V15p_14.Doc
Pages: 3

14. The cursor should be flashing under the RC, enter the desired report code (ex. If 31 enter 3 + 1). Valid entries are 0-9
15. Press [★] to continue to the next zone, repeat steps 12-14
16. To exit ★58 expert mode press 00 then ★ when the cursor is flashing under the ZN, screen displays:
Enter ★ or #
17. Press ★99 to exit program mode.

NOTE: You MUST enable keypad panics in *57 function key programming for key functions A, B, & C by entering 00 for the function.
