




The diagram that appears on bottom of page 9 of the LYNXR-I Installation Instructions reversed the colors of wires at where they are connected to the AlarmNet 7845i-ENT/7845i.

Please use the following diagram if you are installing an AlarmNet 7845i-ENT/7845i with the LYNXR-I.



# Honeywell

165 Eileen Way, Syosset, New York 11791  
Copyright © 2006 Honeywell International Inc.

[www.honeywell.com/security](http://www.honeywell.com/security)



K14114-RMF 10/06 Rev. A