

Lynx-REN

Setting Time & Date

Enter the Installer code + “#” + 63

Enter the two digit hour and press “*”

Note: This is 12-hour format

Press “1” for “PM” or “0” for “AM” and press “*”.

Enter the 2 digit minutes and press “*”

Enter the two digit month and press “*”

Enter the two digit day and press “*”

Enter the two digit year and press “*” to exit