

**ADDENDUM TO: INSTALLATION AND SETUP GUIDE/PROGRAMMING GUIDE
FOR VISTA-20P/VISTA-20PSIA/VISTA-20PCN**

(Use with issue K5305-1V5 and K5305-1PRV5)

RE: Supports Up to Four Touch Screen Devices

This addendum applies to systems with control panel microprocessor version 5.0 or higher.

Touch Screen Device (AUI) Support

The VISTA-20P/VISTA-20PSIA/VISTA-20PCN controls support up to four (4) touch screen style devices, such as the Symphony Advanced User Interface (AUI) and Touch Screen style keypads. When using touch screen devices, be careful not to overdraw the panel's auxiliary power output. A supplemental power supply may be required for the application.

Touch Screen Compatibility Note: To ensure proper touch screen device operation, connect only to controls having microprocessor version 3.0 or higher, and use AUI devices with the following rev levels: Touch Screen style keypads use version 1.0.9 or higher; 8132/8142 (Symphony) series use version 1.1.175 or higher.

Use field *189 to enable touch screen style devices. Refer to the description below when programming this field.

To enable touch screen devices:

1. Enter programming mode.
2. Go to field *189, and at the appropriate locations, enter the partition in which the devices are used.
3. Make sure to set the touch screen devices to the addresses listed in note B in the field description.

| | | |
|--|--|--|
| *189 TOUCH SCREEN DEVICE (AUI) ENABLE | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [1,1,0,0] AUI 1 AUI 2 AUI 3 AUI 4 | The system supports up to four (4) touch screen style keypads (e.g., Symphony, Touch Screen style keypads). Enter each touch screen (AUI) device's home partition. |
| | 0 = disabled 1 = partition 1 2 = partition 2 3 = partition 3 (common) | NOTES: A. Use of AUI does not affect the number of standard keypads supported. B. Touch Screen device addresses must be set as follows: AUI 1: address 1 AUI 2: address 2 AUI 3: address 5 AUI 4: address 6 |

IMPORTANT: If using more than one touch screen device with the system, leave field *197 Exit Time Display Interval set to the default value "0." Touch Screen style keypads automatically display remaining exit time in one-second increments.



165 Eileen Way, Syosset, NY 11791
Copyright © 2007 Honeywell International Inc.
www.honeywell.com/security



K5305-1V5XX 1/07 Rev. A