



ADEMCO GROUP TECHNICAL SUPPORT KNOWLEDGEBASE  
STEP-BY-STEP PROCEDURE

Created: 3.27.2000  
Modified: 3.27.2000  
File: V10se\_24.Doc  
Pages: 1

---

Product: Vista-10SE  
Title: Using External Sounder

- 
1. Connect the Sounding devices to Terminal 3 (+) & Terminal 4 (-) of the control panel, observing polarity.
  2. If bell supervision is desired, cut the white jumper above these terminals & install a 1K resistor in parallel across the last sounding device.
  3. If a clicking noise is emitting from the sounders put a 2A diode in series with the positive side of the bell output, with the silver band going toward the sounders.
- 

**NOTE: 2A max. output @ 10.5-13.8VDC**

---