

Procedure for Setting up Remote Downloading

- | | |
|--------------|---|
| 1. | Enter program mode, Installer Code (5140) + 8 + 0 + 0 + 0 screen displays "PROGRAM MODE * FILL # VIEW -00". |
| 2. | Press *32, screen displays "PRIM. SUBS. ACCT #". |
| 3. | Enter the primary account number in hexadecimal form (i.e. 1234 would be entered as 01 02 03 04) or enter "15" four times for first time communication. |
| NOTE: | If a 3 digit account number is desired press "*" after the last digit is entered. |
| 4. | Press *35, screen displays "DOWNLOAD PHONE" |
| 5. | Enter the callback phone number for the computer, if callback is not desired proceed to step 6. |
| NOTE: | If not using all 17 locations press "*" after the last digit is entered. |
| 6. | Press *36, screen displays "DOWNOAD ID NO." |
| 7. | Enter your CSID number or enter "15" eight times for first time communication. (e.g., if your CSID is 12345678, enter 01 02 03...08) |
| NOTE: | The CSID number CANNOT be displayed from the keypad. |
| 8. | Press *44, screen displays "RING DETECTION COUNT" |
| 9. | Enter the desired ring count between 01-15. If using answering machine defeat enter "15" |
| NOTE: | The ring count is the number of times the phone will ring before the panel picks up & tries to initiate communication. If "15" answering machine defeat was selected you can call up, let the phone ring 1 or 2 times then hang up, call back & the panel will answer. |
| 10. | Press *94, screen displays "ALT PROGRAM MODE * FILL # VIEW 100" |
| 11. | Press *53, screen displays "DOWNLOAD CALLBACK" |
| 12. | Enter 1 for no callback |
| 13. | Press *99, screen displays "PROGRAM MODE * FILL # VIEW -00" |
| 14. | Press *99 to exit program mode before attempting to call the panel. |