

INSTRUCTIONS FOR 6271CVADTHD DEMONSTRATION KEYPAD

The 6271CVADTHD is designed to be a stand-alone TouchCenter keypad for demonstration purposes. The 6271CVADTHD consists of a keypad, power supply (attached to the rear of the keypad), and an AC Adapter. As a stand-alone device, some keypad entries are disabled because they involve actual panel communication. When using the keypad, follow all procedures provided in the 6271CVADT User's Guide except for those items listed in this Supplement.

Disabled Keypad Functions

When using the demonstration keypad, the following screen buttons will not function:

- USER SETUP
- NIGHT SETUP
- CODE AUTHORITY

Limited Keypad Functions

When using the demonstration keypad, the following screen will have limited functionality:

- SHOW ZONES

Defined User Codes

The keypad has three defined user codes stored in memory. These codes are the only codes that are available for use in the keypad and cannot be changed. The codes and authority levels are:

- 4140 = Installer
- 1234 = User with access to three partitions
- 1111 = User with access to partition 1 only

Powering Up the 6271CVADTHD

The 6271CVADTHD keypad is powered by an external AC adapter. To power up the keypad, plug the AC transformer output into the right side of the keypad and plug the transformer into a 115VAC outlet.

Using the 6271CVADTHD

To use the 6271CVADTHD, follow the procedures provided in the 6271CVADT User's Guide while observing the allowable user codes, disabled functions, and limited functions listed previously in this document.

Restoring the Demo Mode

The 6271CVADTHD will be in the demo mode when you receive it. If you take the unit out of the demo mode, please follow the below instructions to resume the demo mode:

1. Press the **Security** button on the "Home" screen. The "Arming" screen is displayed.
2. Press the **More Choices** button on the "Arming" screen. The "More Choices" screen is displayed.
3. Press the **Advanced Setup** button on the "More Choices" screen. The "Authorization" screen is displayed.
4. Enter **4140** as the authorized code. The next screen is displayed.
5. Press the **Central Station** button. The "Central Station" screen is displayed.
6. Press the **Options** button on the Central Station screen. The "Options" screen is displayed.
7. Touch the **Demo Mode** button on the Options screen to turn the Demo Mode on or off. The Demo Mode is enabled when a checkmark appears in the button.
8. Press the **Done** button to accept the change. The "Central Station" screen appears.
9. Press the **HOME** button on the front of the keypad to return to the "HOME" screen.



ADT Security Services, Inc.

One Town Center Road
Boca Raton, FL 33486
Copyright © 2008



K14940-1 8/08 Rev. A